

Reformer concepts for high efficient SOFC systems

Dr. Christian Spitta

Session B1, F-Cell 2012, Stuttgart

ZBT GmbH Carl-Benz-Straße 201 47057 Duisburg Germany

Telefon: +49-203-7598-4277 Telefax: +49-203-7598 2222 www.zbt-duisburg.de c.spitta@zbt-duisburg.de





mCHP Reformer technology at ZBT

Reformer for PEM-FC

- More than 10 years experience
- Nominal H2 output: 2,5-12,5 kW_{th}
- Efficiency: up to 85 %
- Fuels: NG, LPG, Biogas



Features

- No electrical heaters
 - Product level
- Low cost manufacture
- Patented (licence available) in EU, US, CA, JP, Korea

Related R&D

- Desulphurisation
- Long term stability
- - ...

Unit standardisation Testing of adsorbents German project /





- Optimisation of heat integration
- Efficiencies > 85 % 4
 - TÜV certificate

Ar

Air

- Increase efficiency

 For NG coordination (nip)



- Adequate materials and coating
 - Joining technologies

Ar



Source: DFI



Condensing technology


Optimisation of CO cleanup

Optimisation of heat exchanger



Motivation


- High efficient CHP systems play key role in future energy supply
- Possible fuels: Natural gas, LPG or Biogas
- Reducing heat demand for stationary applications
- SOFC technology has potential for high efficiencies and high CHP coefficients
 - Reduction of carbon footprint
 - System operation even at low heat demand



Challenges

- High el. efficiency (comparable to complete internal reforming) leading to continuous operation
- Simple and robust design









Presented reformer configurations


- 1. Biogas reformer module
 - Combined steam and dry reforming
 - Reformer/burner reactor
 - Water connection
 - Evaporator and super heater

2. LPG reformer


- Tube bundle reformer convectively heated by the exhaust gas
- Adiabatic burner
- Recirculation of AOG
- 3. NG reformer
 - Adiabatic reformer
 - Adiabatic burner
 - Recirculation of AOG











Design of reformer module

- Co-flow reformer/burner reactor as two concentric annular gaps with integrated metallic structures
- Precious metal catalysts in reformer and burner
- Counter-flow evaporator and super heater designed as spiral pipe





2011, Lucerne, 2011




Experimental results

Lab characterisation of reformer module at standard operation point

- x_{CH4} = 65 %,
- O/C_{Ref} = 2,5,
- T_{Ref} > 625 °C





of H2 and CO rich fuel gas for SOFC, EFCF 2011, Lucerne, 2011

- Heat transfer guarantees reformer outlet temperature > 625 °C
- > Adjusting of maximum burner temperature by burner air
- Efficiency reformer module > 86 %

 $\eta_{\text{reformermodule}} = \frac{P_{chem, reformer, out}}{P_{chem, reformer, in} + P_{chem, burner, in}}$





1. Biogas reformer module


Experimental results

SOFC system at biogas plant and in lab

- x_{CH4} = 68 %,
- O/C_{Ref} = 2,5,








No carbon formation detected

- Concentrations correspond very well with thermo dynamic equilibrium
- Gross electrical system efficiency 53 % (separate 500h-Lab test at Cutec)

Lindermeir et al.: High efficient biogas electrification by an SOFC-system with combined steam and dry reforming , EFCF 2012, Lucerne, 2012




Simulations results (for Propane)



No carbon formation for


- $ightarrow T_{Ref} \ge 650$ (@ R=8,5; FU=85)
- > $T_{Ref} \ge 725$ (@ R=6; FU=80)

Gross el. system efficiency > ηel = 61 % (@ R=8,5; FU=80) > ηel = 63 % (@ R=8,5; FU=85)



Reformer catalyst pre-tests

- Test reactor: Single tube of the tube bundle reactor (el. heated)
- Inlet temperatures 550-570 °C (according simulation)
- Test of: Fuel conversion, carbon formation & pressure drop
- Fuel: Propane
 - > Very well correspondence with thermo dynamic equilibrium
 - H₂+CO content up to 95 mol-%_{drv}
 - > No carbon formation detected
 - Pressure drop is < 5 mbar</p>






Design of reformer and burner

- > Tube bundle reactor convectively heated by exhaust gas (counter-flow)
- > Precious metal catalysts in reformer and burner


Restrictions

- Sufficient surfaces for heat transfer
- Big difference of flow rates of reformer reactants and exhaust gas
- Pressure drop \leq 5 mbar (for both media)







2. Tube bundle LPG reformer











- Heat for reforming & preheating of anode inlet gas in SOFC ≈ const.
- > $\lambda_{cat} \approx const. \approx 2.5 / 2.7$ (referred to supplied reformate gas)
- With increasing recirculation ratio
 - T_{Ref,inlet} increases up to 722 °C
 - T_{Burner.ad} decreases down to 875 / 857 °C
 - $\eta_{\text{el,gross}}$ increases up to 61 / 62 %



Conclusion

- Presentation of 3 reformer and water supply configurations for 1 kW-class SOFC system
- Simulation for all configurations showed
 - Gross electrical system efficiencies > 50 %
- Tests of biogas reformer module demonstrated
 - Biogas composition fluctuations could be compensated by steam and dry reforming
 - Concentrations correspond very well with thermo dynamic equilibrium
 - High reformer and system efficiencies in Lab and at biogas plant
- Tests of tube bundle LPG reformer showed
 - Good heat transfer from exhaust gas to reformer
 - Low pressure drop in reformer and burner
 - H2+CO content up to 90 mol-%dry

Outlook

- Further proves of concept of biogas SOFC system reformer module at other biogas plants
- Test results on system level with the tube bundle LPG reformer
- Combinations of reformer and water supply concepts
- Scale-up of tube bundle reformer





Thanks to the team members at ZBT for their high effort leading to the presented results.

Thanks to the colleagues from project partner Cutec for the collaboration and contribution in these projects. Furthermore thanks to Staxera GmbH and Nordzucker AG for their support during the projects.

Part of the work was financed with funds of the German "Federal Ministry of Economics and Technology" (BMWi) and is gratefully acknowledged (IGF-projects no. 16126 N and 16638 N).



Thank you for your attention!

Contact: Dr. Christian Spitta <u>c.spitta@zbt-duisburg.de</u> +49 (0)203/7598-4277 www.zbt-duisburg.de

